


No. 98 Coal Bunker

Wiring the Bunker

Place the coal bunker in the desired location on your layout. Connect one binding post on the bunker to the controller and connect the other binding post of the controller to the 14-Volt output of your transformer. The second binding post on the bunker should be connected to the ground on your transformer. The bunker operates best at 14-Volts AC.

Set-Up and Operation

Load coal (not included) into bunker hopper. Press and hold the red push-button on the controller to release the coal in the bunker loft down the chute into the waiting dump cars.



CAUTION: Electrically Operated Product

Recommended for Ages 14 and up. Not recommended for children under 14 years of age without adult supervision. As with all electric products, precautions should be observed during handling and use to prevent electric shock.

WARNING: When using electrical products, basic safety precautions should be followed, including the following:

- Read instructions thoroughly before using this device.
- M.T.H. recommends that all users and persons supervising use examine the hobby transformer periodically for conditions that may result in the risk of fire, electric shock, or injury to persons, such as damage to the primary cord, plug blades, housing, output jacks or other parts. In the event such conditions exist, the transformer should not be used until properly repaired.

As with all electrical appliances, this product should not be left in operation when unattended.

M.T.H. Electric Trains

7020 Columbia Gateway Drive
Columbia MD 21046-1532
phone: 410-381-2580
FAX: 410-423-0009
parts@mth-railking.com